

## Operation Manual

# CHECKLINE®

## MADE TO MEASURE



### Warning

Operators should wear protection such as a mask and gloves in case pieces or components break away from the unit under test.

Whether the unit is ON or OFF, DO NOT exceed the capacity of the sensor. NEVER exceed 120% of the rated capacity, or the sensor will be damaged. At 110% of the rated capacity the display will flash a warning.

Measure in line with the cam apparatus only. DO NOT attempt to measure forces at an angle to the sensor – damage to sensor may result.

Do not attempt to repair or alter this instrument. Warranty will be voided and damage to the unit may result.

Use and store within the stated temperature and humidity ranges, or damage and failure may result.

Ensure during testing unit is used on flat, stable surface.

If not using this instrument for extended periods of time, remove the batteries to prevent potential battery leakage from causing product damage.



The WTPT-1000 Electrical Terminal Wire Tester is a compact, robust, highly accurate test instrument for testing wire terminal test strength. With its all-metal construction and easy clamp cam-loading mechanism, the WTPT enables quick, repetitive, long-term usage on production assembly lines. The +/-0.2% F.S. accuracy combined with 0.01 lb/kg precise resolution produces superb performance for quality control and lab testing. Terminal wheel enables quick selection between 10 different diameter size wires from 0.03 to 0.25" (0.8-6.35 mm).

The WTPT provides long operation life and power flexibility with the ability to work from the internal rechargeable battery or included AC adapter. The analog bar graph on the backlit, LCD aids users by providing the resultant force's current position compared to the full-scale range.

The WTPT has four operations modes: Track, Peak, First Peak, Auto-Peak: Track for live readings, Peak which records the highest level over a test, First Peak which records a reading after a programmed decrease, Auto Peak which resets after a programmed period of time. Additional tolerance function, available in all modes, with programmable thresholds and pass/fail icons produces live test feedback allowing instant determination of the results.

Every tester comes standard with USB and RS-232 outputs. The WTPT's software enables the uploading of data and the additional statistical analysis with its auto-calculation of the selected values. These excellent features make the WTPT-1000 Electrical Terminal Wire Testers a versatile addition to the production, R & D and quality control departments.

### SPECIFICATIONS

**Measuring Capacity:** 224.8 lbf (100 kgf)

**Accuracy:** ± 0.2% of FS

**Wire Size Dia. Range:** 0.03 - 0.25 in; 0.8, 1.0, 1.5, 2.0, 2.5, 3.0, 3.5, 4.0, 5.0, 6.35 mm; AWG 30 - AWG 3

**Minimum Sample Length:** 5.5" (140 mm)

**Maximum Elongation:** 1.7" (44 mm)

**Units of Measure:** N, kgf, lbf, ozf

**Measure Modes:** Track, Peak, First Peak, Auto Peak

**Overload Protection:** 120% of Full Scale

**Sampling Rate:** 2 kHz (Track mode); 8 kHz (Peak Mode); 8 kHz (First Peak); 8 kHz (Auto Peak)

**Display:** 160\* 128 Dot matrix backlit LCD

**Display Update Rate:** 100ms

**Resolution:** 0.01 lbf, 0.1 N, 1 ozf, 0.01 kgf

**Memory:** 1000 data points

**Output:** USB, serial port RS-232, High and low limit NPN

**Battery Indication:** Battery icon flashes when low

**Battery Life:** Approx. 25 Hours continuous on full charge

**Charger/Adapter:** Universal USB charger, input 110 - 240 V ac 50/60 Hz

**Power:** 3.6 VDC 1600 mAh Ni-MH battery pack

**Operating Temperature:** 14 to 104°F (-10 to 40°C)

**Humidity Limit:** 20 - 80% RH

**Dimensions:** 12.9 x 5.4 x 9.8" (327 x 136 x 249 mm)

**Product Weight:** 10.4 lb (4.7 kg)


**Package Weight:** 12.8 lb (5.8 kg)

**Warranty:** 1 year

**Certification:** CE, RoHS



**Included Accessories:** USB cable, charger adapter, cal. cert.

**Optional Accessories:** RS-232 cable, printer cable




## MODE DETAILS


Press can change the mode between Track, Peak, Recommend using peak mode for measurement.



## LCD SCREEN



Tolerance alarm on



## MENU STRUCTURE

Menus	Submenus	Selections
Measurement	Unit	N, kgf, lbf, ozf
	Group	01-99
	Tolerance	Max, Min
	Test Mode	Track, Peak, AutoPeak, Firstpeak
	Peak Time	1-99s
	Alarm	On, Off
Memory	Storage Mode	Single, Auto
	Browse All	
	Browse Selected	
	Delete Selected	
	Delete All	
Printing	Print Recent	
	Print Selected	
	Print All	
	Print Diagram	
	Display Mode	Digital, Diagram
System	Power Off	1~99 minutes
	Backlight	ON, Off, 15s, 30s, 45s, 60s
	Key Tone	ON, Off
	Date/Time	
	Password	
	Key Setting	Print, storage
	Default Setting	
Language	English, Chinese, German	
Calibration		
Information	Model, SN, Version	

## KEY FUNCTIONS



ON/OFF: Push for 1 second to power On or Off.



		Short Press	Long Press
Measuring	Track	Zeroing(tare)	-
	Peak	Update peak	Zeroing(tare)
Menus		Moves selection up Increases the value	-



**Measuring:** Changes the measure mode.  
**Menus:** Moves selection down or move digit.



**Measuring:** Enter the menus.  
**Menus:** Select or Enter.




**Measuring:** Store data.  
**Menus:** Back or quit.


**OPERATION**

Select the corresponding slot width based on the cable diameter.


Rotating terminal fixture



Slot orientation






Install the terminal




**CLAMPING WIRE CABLES**

Rotate the handle clockwise to push the cam away. Insert the cable and release the handle to reset the cam to clamp the cable.





**Loading**

Rotate the handle counterclockwise to load.




**MEASUREMENT MENU**

The Measurement menu contains six selectable items: Unit, Group, Tolerance, Test Mode, Peak Time, and Alarm.




**Unit**

The measuring unit can be selected under this menu. Touch "ZERO" or "MODE" keys to move to the next selection. Press "LOG" to cancel or touch "MENU" to confirm and exit.




**Group**

When several test samples need to be measured, the samples can be coded into groups. The range is 01-99. When set to "00", becomes, "01" automatically. Press "ZERO" to adjust the value, touch "MODE" to shift to the next position. Touch "LOG" to cancel; press "MENU" to confirm and exit.




**Tolerance**

Program high and low limit values to enable ok/ov testing. The lower limit value cannot be greater than the upper limit value, and neither limit value can be greater than 110% of the rated capacity. Press “ZERO” to adjust the value, touch “MODE” to shift to the next position. Press “LOG” to cancel; touch “MENU” to confirm and exit. To activate the limit tolerances, must set to “ON” in the Alarm menu.




**Test Mode**

Change the mode of operation between the four modes. Press “ZERO” or “MODE” keys to select. Press “LOG” to cancel or “MENU” to confirm and exit. This adjustment can also be changed at the home screen display by simply pressing “MODE”. If choosing Auto Peak Mode to set a peak time capturing period, set this time in Peak Time setting menu. First Peak Mode will display a drop ratio menu (Figure -2 ). This drop ratio activates the first peak recording.




**Memory**

In the Memory menu, the user can browse, delete, or print the data.




**Storage Mode**

Select Single to save the displayed value when “LOG” key is pressed. Single is active in all four modes. For continuous data storage, select Series. When a peak capture is achieved, this value will be saved.




Touch “MENU” to see Delete or Print options. Touch “LOG” to go back.




**Browse Selected**

User can choose the data to browse. The available range of data stored is shown. Touch “ZERO” to adjust the value. Press “MODE” to shift to the next position. Press “LOG” to cancel; touch “MENU” to confirm.




**Delete Selected**

Select the range of data to be deleted. Touch “ZERO” to adjust the value. Press “MODE” to shift to the next position. Touch “LOG” to cancel; touch “MENU” to confirm.




**Delete All**

In this menu, a prompt will appear. All data will be deleted by selecting "YES" and canceled by selecting "NO" or pressing "LOG".




**Print All**

To print all data saved in memory, a prompt window will display. All data will be printed by selecting "YES". This operation will be canceled by selecting "NO" or touching "LOG".




**Printing**

The Printing menu contains four selectable items: Print Recent, Print Selected, Print All and Print Diagram. The data saved in memory can be output to a printer through the serial port RS232 connection. (See RS232 for more information)



**Print Recent**

Print recently stored data in this menu. The range is 0~19. Touch "ZERO" to adjust the value. Touch "MODE" to shift to the next position. Press "LOG" to cancel. Press "MENU" to confirm.




**Print Selected**

Select the data range to print. Touch "ZERO" to adjust the value, touch "MODE" to shift to the next position. Press "LOG" to cancel; touch "MENU" to confirm.




**System**

Under the System menu, nine parameters may be set.




**Display Mode**

Two display modes may be selected: Digital and Graphic.



**Power Off**


To maximize battery life, the power can be set to shutdown after non-use. The time can be set in this menu. The range is 01-99 minutes. When set to "99" the gauge will never turn off. Touch "ZERO" to adjust the value, touch "MODE" to shift to the next position. Press "LOG" to cancel; Push "MENU" to confirm and exit.






### Backlight

The backlight can be set to ON, OFF or have a timed auto-off. Touch "ZERO" or "MODE" keys to shift to the next position. Press "LOG" to cancel. Press "MENU" to confirm and exit.




### Key Tone

Turn the key sound ON or OFF. Touch "ZERO" or "MODE" keys to shift to the next position. Touch "LOG" to cancel; Press "MENU" to confirm and exit.




### Date Time

The system time may be set under this menu. Touch "ZERO" to adjust the value. Press "MODE" to shift to the next position. Touch "LOG" to cancel. Press "MENU" to confirm and exit.




### Password

The system password can be changed. The default System password is "123". First, enter the old password, then enter the new password and confirm the new password. Touch "ZERO" to adjust the value. Press "MODE" to shift to the next position. Touch "LOG" to cancel; Push "MENU" to confirm and exit.




### Key Setting



Set the default function of the "LOG" key from the home screen. The function can be set to print or store the current displayed value. Press "ZERO" or "MODE" to select the proper setting. Press "LOG" to cancel; touch "MENU" to confirm and exit. The default value is set to Storage


### RS232 Baudrate

Adjust Baudrate to available bits per second selection.



### Default

When experiencing undetermined issues, the terminal tester can be restored back to the original factory settings. Only perform this operation when all other troubleshooting tactics have been attempted.




### Language

Select between English, German and Chinese




### Calibration


Users can field-calibrate the gauge. First, enter the system password (Default is 123) by pressing the “ZERO” and “MODE” keys. Then press “MENU” to confirm.




Mount the unit in a position to allow addition of a standard weight. A bracket may be required and is offered by Nidec. If a bracket is added, tare this load by pressing “ZERO”. Load a standard force. Wait a moment for the force to stabilize.



The current measured value should equal the standard force applied. If the values do not match, press “ZERO” and the “MODE” keys to correct the measured value. Press “MENU” to enter the next calibration point.



After any of the calibration points have been completed, touch “LOG” to exit the calibration mode. Then save the calibration or discard by pressing “Yes” or “No”. After completing the calibration of the 5th point, the confirmation window will automatically ask to “Save and Exit” by selecting “Yes” or “No”.



### Information

Information includes the model, version of the software and the serial number.



### Charging

The WTPT is supplied with a set of 3 Nickel Metal Hydride AAA rechargeable batteries, which are supplied fully charged to allow immediate use. Users need to recharge batteries when a low battery icon flashes. Users should connect the gauge and the charger using the USB cable. Then connect the charger to an AC socket to start charging. Laptops and other USB devices can also charge the gauge. A fully charged battery pack will provide approximately 25 hours of constant use.

### Rechargeable battery pack:

- Type: Ni-MH 3.6VDC 1600 mAH rechargeable batteries
- Charging time: approx. 3~4 hours
- Battery life: approx. charge and discharge 500 times

### Communication

#### USB

Series WTPT is designed in accordance with USB2.0 standard protocol. The USB Port can be connected to a charger with the USB cable for charging the internal Ni-MH battery and can be connected to a computer for uploading the measured values. Connect the gauge and the computer with the USB cable, then open the computer software. Upload the values. Please refer to the software manual for additional information.




#### RS-232

The RS232 serial port is used to connect a printer to print the memory data.

RS-232 specifications are as follows:

- Data transmission: serial interface
- Synchronization: asynchronous
- Signal Level: RS-232 level, logic 1:-5v, logic 0: +5v
- Hardware Flow Control: None
- Data word length: 8 bits
- Stop bit: 1bit
- Parity: None
- Baud rate: 38400




Pin	Description	Pin	Description
1	RS232 Transm(TX)	5	Reserved
2	RS232 Receiv(RX)	6	Output COM-
3	RS232 Ground	7	Output B+
4	Output A+	8	Reserved

#### DB-9 male



## Comparison Output

Comparison Output internal circuit shown.



When the measured value is less than the lower limit tolerance value, the "pc2" operates, 7pin and 6pin line conduction. When the measured value is more than the upper limit tolerance value or 110% of the rated capacity, the "pc1" operates, 4pin and 6pin line conduction.

Maximum Permissible Voltage  
pin 7 to pin 6, pin 4 to pin 6: 35V;  
pin 6 to pin 7, pin 6 to pin 4: 6V.

## A-1 Dimensions

Unit: mm

